


# Terminate Fire Alarm on ACU1000

## Overview

Fire alarm input act as a master overwrite to Access Control Door during emergency. Those programmed relay output will be deactivated in case fire alarm activated. ACU1000 board has a dedicated input for fire alarm, it must be shorted when not in use. It must be terminate with a pair of dry contact normally close input. When installing more panel, the fire alarm signal can must connect in parallel.



Note: Related Document SD0035