

Terminate ACU1000 Output Board

Overview

ACU1000 output board is an extension board to ACU1000 Main Board, its extend the number of output monitoring zone to 32.

1. DC Output 12V
2. Output Zone 1 to 32




Figure 1. ACU1000 Output Board

1. On Board power input DC12V In.
2. There are total 32 output relay zone on the Output board, all 32 can use for device triggering or locking mechanism locking purpose.
3. Each of the relay can be jumper configure to voltage out 12V DC or voltage free switch output. The output can also be configure to be normally open or normally close.

Please see related document SD0020, SD0044